Maintenance Schedule (Normal Conditions)

Service at the indicated distance or time – whichever comes first.	miles x 1,000	15	30	45	60	75	90	105	120
	km x 1,000	24	48	72	96	120	144	168	192
	months	12	24	36	48	60	72	84	96
Replace engine oil		Replace every 7,500 miles (12,000 km) or 12 months							
Replace engine oil filter		●	●	●	●	●	●	●	●
Check engine oil and coolant		Check oil and coolant at each fuel stop							
Replace air cleaner element			●		●		●		●
Inspect valve clearance			Adjust only if noisy					●	
Replace spark plugs	For 4-cylinder models		●		●		●		●
	For V6 models							●	
Replace timing belt, balancer belt*1, and inspect water pump								●	
Inspect and adjust drive belts			●		●		●		●
Inspect idle speed								●	
Replace engine coolant				●		●		●	
Replace transmission fluid							●		
Inspect front and rear brakes		●	●	●	●	●	●	●	●
Replace brake fluid				●			●		
Check parking brake adjustment		●	●	●	●	●	●	●	●
Replace air conditioning filter			●		●		●		●
Rotate tires (Check tire inflation and condition at least once per month)		Rotate tires every 7,500 miles (12,000 km)							
Visually inspect the following items:									
Tie rod ends, steering gear box, and boots Suspension components, driveshaft boots Brake hoses and lines (including ABS) All fluid levels and condition of fluids Cooling system hoses and connections #Exhaust system, #fuel lines and connections		●	●	●	●	●	●	●	●

Follow the Normal Conditions Maintenance Schedule if the severe driving conditions specified in the Severe Conditions Maintenance Schedule do not apply.

NOTE: If you only *OCCASIONALLY drive* under a "severe" condition, you should follow the Normal Conditions Maintenance Schedule.

* 1: Balancer belt applies to 4-cylinder models only.

: See information on maintenance and emissions warranty, last column, page 197.

Maintenance Schedule for Normal Conditions (listed by distance/time)

Service at the indicated distance or time, whichever comes first. Do the items in **A, B, C** as required for each distance/time interval. Follow this schedule if the severe driving conditions described in the Severe Conditions Schedule on the next page do not apply.
Canadian owners: Follow the schedule for Severe Conditions.

7,500 mi/12,000 km/-	Do items in A.
15,000 mi/24,000 km/1 yr	Do items in A, B.
22,500 mi/36,000 km/-	Do items in A.
30,000 mi/48,000 km/2 yrs	Do items in A, B, C.
37,500 mi/60,000 km/-	Do items in A.
45,000 mi/72,000 km/3 yrs	☐Replace coolant. ☐Replace brake fluid. Do items in A, B.
52,500 mi/84,000 km/-	Do items in A.
60,000 mi/96,000 km/4 yrs	Do items in A, B, C.
67,500 mi/108,000 km/-	Do items in A.
75,000 mi/120,000 km/5 yrs	☐Replace coolant. Do items in A, B.
82,500 mi/132,000 km/-	Do items in A.
90,000 mi/144,000 km/6 yrs	☐Replace brake fluid. ☐Replace transmission fluid. Do items in A, B, C.
97,500 mi/156,000 km/-	Do items in A.
105,000 mi/168,000 km/7 yrs	☐*Replace timing belt*1, balancer belt*2, inspect water pump*1. ☐Replace coolant. ☐Inspect valve clearance. ☐Check idle speed. ☐Replace spark plugs (V6 models). Do items in A, B.
112,500 mi/180,000 km/-	Do items in A.
120,000 mi/192,000 km/8 yrs	Do items in A, B, C.

A	☐Replace engine oil. ☐Rotate tires (follow pattern on page 244). ☐Adjust valves if noisy.
B	☐Replace engine oil filter. ☐Inspect front and rear brakes. ☐Check parking brake adjustment. ☐Inspect tie rod ends, steering gear box and boots. ☐Inspect suspension components. ☐Inspect driveshaft boots. ☐Inspect brake hoses and lines (including ABS). ☐Check all fluid levels, condition of fluids, and check for leaks. ☐Inspect cooling system hoses and connections. ☐*Inspect exhaust system. ☐*Inspect fuel lines and connections.
C	☐Replace air cleaner element. ☐Replace spark plugs (4-cylinder models). ☐Inspect and adjust drive belts. ☐Replace air conditioning filter.

* : See information on maintenance and emissions warranty, last column, page 197.
*1 : See Tim ing Belt on page 240 to determine need for replacement.
*2 : Balancer belt applies to 4-cylinder models only.

Maintenance Schedule (Severe Conditions)

Service at the indicated distance or time whichever comes first.	miles x 1,000	15	30	45	60	75	90	105	120
	km x 1,000	24	48	72	96	120	144	168	192
	months	12	24	36	48	60	72	84	96
Replace engine oil and oil filter		Replace every 3,750 miles (6,000 km) or 6 months							
Check engine oil and coolant		Check oil and coolant at each fuel stop							
Clean (○) or replace (●) air cleaner element Use normal schedule except in dusty conditons		○	●	○	●	○	●	○	●
Inspect valve clearance			Adjust only if noisy					●	
Replace spark plugs	For 4-cylinder models		●		●		●		●
	For V6 models							●	
*Replace timing belt*2, balancer belt*1, and inspect water pump								●	
Inspect and adjust drive belts			●		●		●		●
Inspect idle speed								●	
Replace engine coolant				●		●		●	
Replace transmission fluid			●		●		●		●
Inspect front and rear brakes		Inspect every 7,500 miles (12,000 km) or 6 months							
Replace brake fluid				●			●		
Check parking brake adjustment		●	●	●	●	●	●	●	●
Replace air conditioning filter*3			●		●		●		●
Lubricate all hinges, locks and latches		●	●	●	●	●	●	●	●
Rotate tires (Check tire inflation and condition at least once per month)		Rotate tires every 7,500 miles (12,000 km)							
Visually inspect the following items:									
Tie rod ends, steering gear box, and boots Suspension components, driveshaft boots		Every 7,500 miles (12,000 km) or 6 months							
Brake hoses and lines (including ABS) All fluid levels and conditions of fluids Cooling system hoses and connections *Exhaust system, *fuel lines and connections Lights and controls, vehicle underbody		●	●	●	●	●	●	●	●

U.S. Owners

Follow the Severe Conditions Maintenance Schedule if you drive your vehicle *MAINLY* under one or more of the following conditions:

- Driving less than 5 miles (8 km) per trip or, in freezing temperatures, driving less than 10 miles (16 km) per trip.
- Driving in extremely hot [over 90°F (32°C)] conditions.
- Extensive idling or long periods of stop-and-go driving.
- Trailer towing, driving with a roof top carrier, or driving in mountainous conditions.
- Driving on muddy, dusty, or de-iced roads.

For Canadian Owners

Follow the Maintenance Schedule for Severe Conditions.

*1 : Balancer belt applies to 4-cylinder models only.

*2 : Refer to page 240 for replacement information under special driving conditions.

*3 : Refer to page 239 for replacement information under special driving conditions.